

Installation Instructions

WC Series

IMPORTANT

Primex recommends the installation of Primex wall caps be carried out by a professional and to comply with all local building codes, standards and regulations.

INSTALLATION INSTRUCTIONS

1. For intake vent use, remove the damper located inside of the wall cap.
2. For use in dryer applications, use Primex "NS" (no screen) model products.
3. Select an appropriate location for the wall cap. Ensure that the location of the wall cap does not conflict with the local building codes and standards.
4. Create a wall cap opening corresponding to the size and shape of the vent's duct.
5. Insert the wall cap vent into the opening with the TOP as indicated on the flange. Fully insert and align the wall cap pipe through the opening.
6. Use the mounting holes on the flange to fasten the wall cap through the building paper to the wall with nails or screws.
IMPORTANT: fasten only the top and side edges, leaving the bottom edge of the vent unattached to the walls.
7. To prevent rain and moisture penetration into the structure apply polyurethane based caulking on the top and side edges of the wall cap flange. Do not caulk the bottom edge, this will allow dissipation of any trapped moisture or incidental water.
8. Install exterior finish and trim around the wall cap.

